INSTRUCTION MANUAL

THERMO HYGRO-ANEMOMETER





INTRODUCTION

Congratulations on your purchase of the unique 3 in one Anemo-Thermometer, the meter features dual display of Air Velocity and Temperature or Relative Humidity with Dew Point . Simple and easy to operate, 7 units to be switchable.

A pocket-knife design makes it convenient and portable , easy to use and to get a precision reading.

Read throughly before using the meter, the unit was calibrated before shipment . There are several models of minianemometer and weather meter available ,please contact with your store for more detail information .

FEATURES/FUNCTIONS

-	Temp./Windchill	: update	every second
---	-----------------	----------	--------------

- Windspeed : update every second,

5, 10, 13 second moving

average are selectable.

 Relative Humidity : response time is 15 seconds. Update

every 2 seconds.


- Temperature sensor : Sealed precision thermister.
- Humidity sensor : Capacitor sensor.
- Water resistant shock proof to 1 M .
- **Data hold** by one button operation.
- Records Maximum reading.
- Unit °C/°F switchable.

 Safety lanyard makes it carry around and avoids falling over.
Material supplied : Meter, Battery CR2032, safety lanyard and manual.

RANGE / RESOLUTION


Unit		Range	RS	
MS	Meter per second	1.1~20.0	0.1	
FPM	Feet per minute	60~3937	2	
KNT	Knot	0.4~38.8	0.1	
КМН	Kilometer per hour	0.8~72.0	0.1	
MPH	Mile per hour	0.5~44.7	0.1	
BF	Beaufort	1~8	1	
RH%	Relative Humidity	5~95	0.1	
DP	Dew Point	0~50	0.1	
°C	Centigrade	-18~50	0.1	
°F	Fahrenheit	0~122	0.1	

"RS" stands for Resolution.



DESCRIPTION

- 1. Vane impeller
- 2. Precision thermister
- 3. LCD display
- 4. ON/OFF and HOLD key
- 5. UNITS and MODE key
- 6. Battery compartment(on rear)
- 7. Swivel handle and storage case
- 8. Lanyard holder
- 9. Humidity sensor
- 10. Tripod mount (on the bottom)



FULL DISPLAY:

Though you have seen HI (Heat Index), it is an optional feature on new model 8909/8910.



POWER ON / OFF

To monitor the air velocity measurement , always position the meter to the air source from the rear of the meter .i.e. the display face to the user .

By pressing the **ON/OFF/HOLD** key momentarily. The Dual Display will illuminate. The top (larger) display indicates air speed and the lower display indicates temperature.(See Fig. 1)

Press and hold **ON/OFF/HOLD** key for approx. 3 seconds to turn the meter off . The meter will also power off after 20 minutes of inactivity .





SELECT AIR VELOCITY UNITS

When normal mode , the LCD shows temperature units (°C or °F) and Air Velocity units. Note: The meter defaults unit KNT °F (See Fig.2).

If you want to change the air velocity unit , simply press the UNITS/MODE key and ON/OFF HOLD key simultaneously , until the display is turns on , while the display is blinking , release only ON/OFF HOLD key , and repeatedly press the UNITS/MODE until the desired units are displaying. The unit cycles through **KNT**, **BF**, **FPM**, **MPH**, **MS**, **KMH** (See Fig. 3, 4, 5 for examples) and then back to the normal display in 5 seconds .





MPH

6 Fig.2



Fig.4

• Fig.5

CHANGE THE LOWER DISPLAY PARAMETER

If want to change display parameter: When the meter is on, press and hold **ON/OFF/HOLD**, meantime press the **UNITS/MODE** key repeatedly to select through Temperature (°F/°C), Humidity (%RH), Dew Point (TD) and Wind Chill Temperature (WCI). The bigger character at the center display is Air Velocity, the smaller character is the value of the desired units. At the right lower section will be either °C or °F or RH%, at the left lower section will be **either TD** or WCI.(See Fig.6, 6-1, 6-2, 6-3)



€ <u>Fig.6</u>







Fig.6-2

fig.6-3

TEMPERATURE UNIT

To select the temperature units: Turn the meter OFF first. Press and hold down both buttons until the display turns on and begins blinking then release the buttons.

Press both buttons momentarily to change temperature unit. After 5 seconds, the meter switches back to normal opration mode automatically.

MAX. OPERATION (only for windspeed)

After a measurement session, press and hold the **UNITS/MODE** key until the **MAX** icon appears on the lower left-hand side of the LCD. (<u>See Fig. 7</u>). Air Velocity indication on the top display will represent the highest readings measured since the meter was last powered.



AVERAGE MODE (only for windspeed)

Normally the meter update windspeed readings every 1 second. You will see no icon is appeared (Fig.8).

To select **5**, **10** or **13** seconds averaging, first press and hold the **UNITS/MODE** key until the **MAX** icon appears.(<u>See Fig.7</u>). Next, press the key again momentarily and the icon will appear with **AVG** icon, it stands for the 13 second average mode now is selected. (<u>See Fig.8-1</u>). The lower icon cycles through **MAX**, **AVG(13)**, **5**, **10**, no icon.



🕥 <u>Fig.8</u>

Now press the key once more for a 5 second average mode, display shows as <u>Fig.9</u>.

Press one more time for a 10 second average mode , display now shows as Fig 10. To return to normal operation press the **UNITS/MODE** key repeatedly until all lower left-hand icons disappear.



∩ <u>Fig.9</u>

∂ Fig.10

DATA HOLD

(To freeze the most recent display), by pressing and holding the **ON/OFF/HOLD** key while taking measurements.To return to normal operation release the key and restart the meter.

WIND CHILL INDICATOR

When power is on , press and hold ON/OFF/HOLD button, then press UNITS/MODE keys to select from °C or °F , RH% , TD then WCI ,when WCI icon appears , release UNITS/MODE button first , then immediately release ON/OFF/HOLD button . (See Fig.11) Otherwise, the meter will turn off after

3 seconds, The temperature display will now factor in the wind chill.



1 Fig.12

To return to the normal mode , follow the same step as above, press **ON/OFF/HOLD** and **UNITS/MODE** simultaneously and momentarily press **UNITS/MODE** button to escape **WCI** (Windchill)and **TD** (Dew Point) features.

NOTE:

When it is in the normal mode with **WCI** or **TD** function , if you keep pressing **UNITS /MODE** button , you will see either MAX or AVG or 5 or 10 appears at the lower corner, IT DOESN'T STAND FOR ANY. As those maximum or average recalling for only Wind Speed .(See Fig.12)

UNITS CONVERSION TABLE

	1 MS	1 FPM	1 KNT	1 KMH	1 MPH
MS	1	0.00508	0.5144	0.2778	0.4464
FPM	196.87	1	101.27	54.69	87.89
KNT	1.944	0.00987	1	0.54	0.8679
кмн	3.6	0.01829	1.8519	1	1.6071
MPH	2.24	0.01138	1.1523	0.6222	1

BATTERY REPLACEMENT

If the meter will not power up as usual or the display contrast becomes weak and difficult to read, replace the lithium battery. To do so, turn the battery compartment cover in a **CLOCKWISE** direction to remove it. (<u>See Fig.13</u>) The battery will be visible in the battery compartment, observe the position of the battery and replace the new one in the same position. Affix the battery compartment cover by turning it in a **COUNTER-CLOCKWISE** direction. Dispose of the lithium battery in accordance with local, state, or national waste disposal codes.


WARNING :

Ensure you have turn off the meter before opening the battery compartment.



VANE REPLACEMENT

NOTE: The anemometer is very accurate at low and mid-range air speeds. Constant use at very high speeds, such as measurements out a fast-moving car window may damage the impeller's bearing and reduce over-all accuracy.



6 Fig.14

To replace the impeller, use a small screwdriver to loosen the set-screw found on the back of the windmeter. The remove the impeller by twisting the impeller assembly clockwise (if you are facing the back of the windmeter) to the **"O"** position marked on the rear of the rear of the meter. (See Fig.14)

Install a new impeller by following these instructions in reverse.

SPECIFICATION

Min/Max.Windspeed	0.5~44.7 MPH
Min/Max.Windspeed	60~3937 FTM
Average readings	5/10/13 second
Dimension	(180° fully opened) 235 x 45 x 25mm
Dimension	(90° folded) 140 x 45 x 25mm
Impeller Dia.	33 x 16 mm (T)
Unit in Imperial	^O F ,FTM ,MPH
Unit in Metric	°C ,MS ,KMH
Unit	KNT, BF
Operating Temperature	-15°C~50°C
Respone time :	
Wind Speed	1 second
Temperature	1 minute
Relative Humidity	15 seconds
Accuracy:	
Wind Speed	±4% (See below)
Temperature	± 1°C or±1.8°F
Relative Humidity	± 3%(5~95%RH)
Dew Point	$\pm 2^{\circ}$ C or $\pm 3.6^{\circ}$ F
WindChill	± 3% F.S
Beaufort	±4% (See below)

The windspeed accuracy is $\pm 4\%$ or $\pm last$ significant digit, whichever is greater. The sample time for air velocity and temperature is a reading per second ,but 1 reading per 15 seconds for humidity with 2 seconds updates .

WARRANTY

The meter is warranted to be free from defects in material and workmanship for a period of one years from the date of purchase.

This warranty covers normal operation and does not cover batteries, misuse, abuse, alteration, tampering, neglect, improper maintenance, or damage resulting from leaking batteries. Proof of purchase is required for warranty repairs.

RETURN AUTHORIZATION

Authorization must be obtained from the supplier before returning items for any reason. When requiring a RA (Return Authorization), please include data regarding the defective reason, the meters are to be returned along with good packing to prevent any damage in shipment and insured against possible damage or loss.

CE CERTIFICATION

The meter conforms to the following standards:

* EN 50081-1/1992 : EN 55022

* EN 50082-1/1997 : EN 55024

(EN 61000-4-2/-3/-8,ENV 50204) , the meter complies with the essential protection requirements of Council Directive 89/336/EEC on the approximation of the laws of the Member States relating to electromagnetic compatibility.

Accuracy, the Zenith of Measuring / Testing Instruments !

Hygrometer/Psychrometer Thermometer Anemometer Sound Level Meter Air Flow meter Infrared Thermometer K type Thermometer K.J.T. type Thermometer K.J.T.R.S.E. type Thermometer pH Meter **Conductivity Meter** T.D.S. Meter D O Meter Saccharimeter Manometer Tacho Meter Lux / Light Meter Moisture Meter Data logger Temp./RH transmitter Wireless Transmitter

More products available !

2008.06rev